

NAME: Naishadh Parikh

Assignment: Windows Server – Shared Folder and NTFS Permissions

1. Create a Shared Folder Named 'MusicLibrary'

Steps:

1. Create a folder named MusicLibrary (e.g., C:\MusicLibrary).
2. Right-click the folder and select Properties.
3. Open the Sharing tab.
4. Click Advanced Sharing.
5. Check Share this folder.
6. Set the share name as MusicLibrary.
7. Click Permissions.
8. Remove the Everyone group.
9. Click Add and select the Students group.
10. Allow only the Read permission.
11. Click Apply and OK.

Result: The MusicLibrary folder is shared, and only members of the Students group have Read access through the network share.

2. Configure NTFS Permissions on 'MusicLibrary'

Steps:

1. Right-click the MusicLibrary folder and select Properties.
2. Open the Security tab.
3. Click Advanced.
4. Click Add and select the Students group.
5. Allow the following permissions:
 - o Read & Execute
 - o List Folder Contents
 - o Read
 - o Write
6. Click Show Advanced Permissions.

7. Find the Delete permission and select Deny.
8. Click Apply and then OK.

Result: Members of the Students group can read, create, and edit files, but they cannot delete any files in the MusicLibrary folder.

3. Map the Shared Folder and Test Permissions

Steps:

1. On the Windows client, open File Explorer.
2. Click This PC → Map Network Drive.
3. Choose a drive letter (e.g., Z:).
4. Enter the shared folder path:

\\ServerName\MusicLibrary

or

\\192.168.1.10\MusicLibrary

(Replace the server name or IP address with your actual server details.)

5. Click Finish.
6. Perform the following tests:
 - o Copy a file into the shared folder.
 - o Edit the copied file.
 - o Try to delete the file.

Results

Action	Result	Reason
--------	--------	--------

Copy a file	Successful	NTFS Write permission allows creating files.
-------------	------------	--

Edit a file	Successful	NTFS Write permission allows modifying file contents.
-------------	------------	---

Delete a file	Failed	The Delete permission is explicitly denied in NTFS permissions.
---------------	--------	---

Explanation

Although the Students group has permission to create and edit files, the Delete permission is explicitly denied through NTFS permissions. Therefore, users can save and modify files but cannot remove them from the shared folder.

4. Create a Second Shared Folder 'PhotoShare'

Steps:

1. Create a folder named PhotoShare (e.g., C:\PhotoShare).
2. Right-click the folder and select Properties.
3. Open the Sharing tab.
4. Click Advanced Sharing.
5. Check Share this folder.
6. Set the share name as PhotoShare.
7. Click Permissions.
8. Remove Everyone.
9. Click Add and add your user account.
10. Grant Full Control permission.
11. Click Apply and OK.
12. Open the Security tab.
13. Remove unnecessary users/groups if required.
14. Add your user account.
15. Grant Full Control.
16. Click Apply and OK.

Testing

1. Log in using another user account.
2. Try to open:

\\ServerName\PhotoShare

Result

The second user cannot access the PhotoShare folder and receives an Access Denied message because only the specified user account has Share and NTFS Full Control permissions.